

Crankcase Gasket
MICFL-110100055-0001



Countershaft Drive Sprocket
MICFL-191600016-0001



LH Front Cover Gasket
MICFL-110420022-0001



RH Crankcase Gasket
MICFL-110620032-0001



Cylinder Head
MICFL-120080928-0004



Valve Cover
MICFL-120280003-0018



Cylinder Head Stopper Plate
MICFL-140200001-0001



Cylinder Head RH Side Cover Gasket
MICFL-120370003-0001



Cylinder Head RH Side Cover
MICFL-120350016-0002



Camshaft Assy
MICFL-140020004-0001



Cylinder Head LH Side Cover
MICFL-120300002-0010



Cylinder Head Seal Gasket
MICFL-120250010-0001



Cylinder Head Cover
MICFL-120230007-0020



Cylinder Assy
MICFL-12002000A



Cylinder Body
MICFL-120020007-0001



Cylinder Head Gasket
MICFL-120150057-0001



Chain Guide Wheel
MICFL-141240001-0001



Cylinder Body Gasket
MICFL-120050044-0001



Piston
MICFL-130030152-0001



Piston Assy
MICFL-1300A0000



Piston Ring Assy
MICFL-130070019-0001



Timing Driven Sprocket
MICFL-140580002-0001



Timing Chain
MICFL-140610001-0001




Clutch Assy
MICFL-500280450-0001



Primary Driven Gear
MICFL-190360016-0001



Primary Clutch Housing
MICFL-190100018-0001



Primary Clutch Shoe Assy
MICFL-190180021-0001



Starter Motor Assy
MICFL-270350033-0015



Chain Guide
MICFL-141000001-0001



Starter Chain
MICFL-193270001-0001




Electric Start Driven Pulley Assy
MICFL-193170022-0001



Ignition Switch Assy
MICF9RHV-169210-1004



 Seat Rubber Sleeve MICF7020-130001	 Front Fender Damper MICF8080-040064	 Push Rivet for Cover MICF9060-040310	 Bolt M6*1.0*20 MICF30006-060020810
 Front Lower Swing Arm MICF9RHV-050210-1000	 Lock Nut M10x1.25 MICF30204-102810	 Mounting Shaft, Front Lower Swing Arm MICF5BY0-050203	 Ball Pin Assy MICF9RHV-050010-1000-20
 Damping Sleeve, Front Upper Swing Arm MICF5BY0-050102	 Middle Spacer, Front Lower Swing Arm MICF5BY0-050201	 Front Upper LH Swing Arm Assy MICF9RHV-050110-1000	 Front Upper RH Swing Arm Assy MICF9RHV-050310-1000
 Buffering Collar MICF9010-050500	 RH Steering Knuckle MICF9RHV-050801-1000	 Cap, Cushion Sleeve MICF9010-050003	 LH Steering Knuckle MICF9RHV-050701-1000



 1-Type Nut MICF30207-102810	 Cotter Pin 2.0X16 MICF30903-0201610	 Bolt M10x1.25x30 MICF30006-102030810	 Sway Bar Seat MICF5BYA-060003
 Front Brake Pad Assy 85mm X 42mm MICF9RHV-0813A0	 Rear Brake Pad Assy 94mm X 47mm MICF9RHV-0815A0	 Rubber Sleeve MICF9030-180008	 Hand Grip Rubber Sleeve MICF9DQV-100005-3000
 Steering Shaft Spherical Inner Bushing MICF7020-100602	 Nut M6*1.0 MICF30202-060110	 Outer Spherical Bearing MICF7020-100600	 Clutch Pull Binding MICF6KJ0-100002
 Spline Sleeve MICF9CR6-103003	 Clamp Dia14.5 MICF6070-120400	 Fuel Pump Assy. MICF0UHV-150900-2000	 Quick Joint MICF6KJ0-120330-10000



Battery Tie Band
MICF9RHV-150700-1001



Inner Hex Bolt M6x14
MICF5BWV-040001-5000